

Repeater (Receiver & Transmitter)

Extension of signal reach distance between bell and receiver. Useful in hotels or beach clubs, pool areas, golf courses and yacht club.

SPECIFICATION

Size:	146W×90L×32H (mm)
Weight:	116g
Color:	Glossy-black top and White bottom
Display:	LCD(in the Bottom) for Mode setting
Freq:	434Mhz Band
Power Supply:	AC220V/DC12V External Adapter
Antenna:	External Dipole antenna
Transmission Type:	Omnidirectional (360°)
RF:	Receiver & Transmitter (FSK Low Power Data Transmission Standard)

FEATURES

- Extend distance between Bell and Pager
- Amplify the weak signal for the site of signal failure
- Bell ID Registered Quantity : max. 500
- Can be Select Bell-Repeater mode or Pager- Repeater mode for the installation environment
- Can be set the Duplicated data transmission time for the optimum propagation conditions
- Can be set the Transmission time per individual repeaters for the optimum Cell Planning
- Available a Wall mounted type or Ceiling type
- Bell ID Registration method : by Air Registration
- Easy registration Call number and easy change Call number through the Air register
- 1,3" LCD Screen
- Mount point: Wall or ceiling