

Nurse Call Bell [Call / Cancel Button (Transmitter) with Curled Cabled Push-Button]

The console is equipped with call and cancel buttons, i.e. the call reset button.

Through the application of Low Power energy-saving technologies, the battery life is extended to 3 years.

Once the signal is transmitted, the bright light-emitting diode starts glowing for three seconds on the console.

When using SB6 consoles with SL5 lamps and/or monitoring and statistics program, it is possible to reset the call signal only by pressing the "cancel" button in the room.

Size:	100×60x6,5 (mm.)
-------	------------------

Weight:	50g
---------	-----

Radio Frequency:	433Mhz, GFSK, PCB Antenna
------------------	---------------------------

Power supply:	CR2450 Lithium batter x 2 pcs
---------------	-------------------------------